

YOLOv4_Series_Custom_Training

July 22, 2021

1 TRAIN A CUSTOM YOLOv4-tiny OBJECT DETECTOR USING GOOGLE COLAB

(A MODIFIED TUTORIAL FOR BEGINNERS)

2 In this tutorial, we will be training our custom detector for fps game body detection using YOLOv4(-tiny) and Darknet

2.1 This notebook was originally created by tech zizou, and now modified by jiapai12138

3 HOW TO BEGIN?

- Click on **File** in the menu bar and click on **Save a copy in drive**. This will open a copy of my colab notebook on your browser which you can now use.
- Next, once you have opened the copy of my notebook and are connected to the Google Colab VM, click on **Runtime** in the menu bar and click on **Change runtime type**. Select **GPU** and click on save.

4 FOLLOW THESE 10 STEPS TO TRAIN A YOLOv4-tiny-based OBJECT DETECTOR USING GOOGLE COLAB

```
[ ]: # Change the current working directory
!pwd
!nvidia-smi
%cd SwitchFrequencyAnalysis
```

5 1) Clone darknet git repository onto the Colab VM

```
[ ]: !git clone https://github.com/AlexeyAB/darknet
```

6 2) Create *yolov4-tiny* and *training* folders in your drive

- Create a folder named *yolov4-tiny* in your drive.
- Next, create another folder named *training* inside the *yolov4-tiny* folder. This is where we will save our trained weights (This path is mentioned in the obj.data file which we will upload later)

7 3) Create & upload these files

What we need for training custom yolo detector

- a. Labeled Custom Dataset
- b. Custom cfg file
- c. obj.data and obj.names files
- d. process.py file (to create train.txt and test.txt files for training)

7.1 3(a) Upload the Labeled custom dataset *obj.zip* file to the *yolov4-tiny* folder on your drive

Create the zip file **obj.zip** from the **obj** folder containing both the input image “.jpg” files and their corresponding YOLO format labeled “.txt” files.

Upload the zip file to the *yolov4-tiny* folder on your drive.

7.2 3(b) Create your custom *config* file and upload it to your drive

Download the *yolov4-tiny-custom.cfg* file from *darknet/cfg* directory, make changes to it, and upload it to the *yolov4-tiny* folder on your drive .

You can also download the custom config files from the official [AlexeyAB Github](#)

You need to make the following changes in your custom config file:

- change line batch to batch=64
- change line subdivisions to subdivisions=16
- change line max_batches to (classes*2000 but not less than number of training images, but not less than number of training images and not less than 6000), f.e. max_batches=6000 if you train for 3 classes
- change line steps to 80% and 90% of max_batches, f.e. steps=4800, 5400
- set network size width=416 height=416 or any value multiple of 32
- change line classes=80 to your number of objects in each of 2 [yolo]-layers
- change [filters=255] to filters=(classes + 5)x3 in the 2 [convolutional] before each [yolo] layer, keep in mind that it only has to be the last [convolutional] before each of the [yolo] layers. (So if classes=1 then it should be filters=18. If classes=2 then write filters=21)

7.3 3(c) Create your *obj.data* and *obj.names* files and upload them to your drive

7.3.1 *obj.data*

```
classes = 2
train = data/train.txt
valid = data/test.txt
names = data/obj.names
backup = /mydrive/yolo/training
```

7.3.2 *obj.names*

```
live-body
dead-body
```

7.4 3(d) Upload the *process.py* script file to the *yolov4-tiny* folder on your drive

To divide all image files into 2 parts. 90% for train and 10% for test.

This *process.py* script creates the files *train.txt* & *test.txt* where the *train.txt* file has paths to 90% of the images and *test.txt* has paths to 10% of the images.

Content of *process.py* shown below:

```
import os

# Current directory
current_dir = os.path.dirname(os.path.abspath(__file__))
print(current_dir)
current_dir = 'data/obj/'

# Percentage of images to be used for the test set
percentage_test = 10

# Create and/or truncate train.txt and test.txt
file_train = open('data/train.txt', 'w')
file_test = open('data/test.txt', 'w')

# Enable multiple extension names
types = ('.jpg', '.png', '.JPG', '.jpeg')

# Populate train.txt and test.txt
counter = 1
index_test = round(100 / percentage_test)
for pathAndFilename in os.listdir(current_dir):
    title, ext = os.path.splitext(pathAndFilename)

    if ext in types:
        if counter == index_test:
            counter = 1
```

```

        file_test.write(current_dir + title + ext + '\n')
    else:
        counter += 1
        file_train.write(current_dir + title + ext + '\n')

file_train.close()
file_test.close()

```

8 4) Mount drive and link your folder

```

[ ]: #mount drive
%cd ..
from google.colab import drive
drive.mount('/content/gdrive')

# this creates a symbolic link so that now the path /content/gdrive/My\ Drive/
↪ is equal to /mydrive
!ln -s /content/gdrive/My\ Drive/ /mydrive

# list contents in yolo folder in your drive
!ls /mydrive/yolo

```

9 5) Make changes in the makefile to enable OPENCV and GPU

```

[ ]: # change makefile to have GPU and OPENCV enabled
# also set CUDNN, CUDNN_HALF and LIBSO to 1

%cd /content/darknet/
!sed -i 's/OPENCV=0/OPENCV=1/' Makefile
!sed -i 's/GPU=0/GPU=1/' Makefile
!sed -i 's/CUDNN=0/CUDNN=1/' Makefile
!sed -i 's/CUDNN_HALF=0/CUDNN_HALF=1/' Makefile
!sed -i 's/LIBSO=0/LIBSO=1/' Makefile

```

10 6) Run make command to build darknet

```

[ ]: # build darknet
!make

```

11 7) Copy files from your drive to the darknet directory

```
[ ]: # Clean the data and cfg folders first except the labels folder in data which
      ↳ is required

      %cd data/
      !find -maxdepth 1 -type f -exec rm -rf {} \;
      %cd ..

      %rm -rf cfg/
      %mkdir cfg

[ ]: # copy the datasets zip file to the root darknet folder
      !cp /mydrive/yolo/obj.zip ../

      # unzip the datasets and their contents so that they are now in /darknet/data/
      ↳ folder
      !unzip ../obj.zip -d data/

[ ]: # copy the custom cfg file from the drive to the /darknet/cfg/ folder
      !cp /mydrive/yolo/yolov4-tiny-custom.cfg ./cfg

      # Copy the custom file so that it is now in /darknet/cfg/ folder
      !cp /mydrive/yolo/yolov4-custom.cfg ./cfg

[ ]: # copy the obj.names and obj.data files so that they are now in /darknet/data/
      ↳ folder
      !cp /mydrive/yolo/obj.names ./data
      !cp /mydrive/yolo/obj.data ./data

[ ]: # copy the process.py file from the drive to the darknet directory
      !cp /mydrive/yolo/process.py ./
```

12 8) Run the process.py python script to create the train.txt & test.txt files inside the data folder

```
[ ]: # run process.py ( this creates the train.txt and test.txt files in our darknet/
      ↳ data folder )
      !python process.py

      # list the contents of data folder to check if the train.txt and test.txt files
      ↳ have been created
      !ls data/
```

13 9) Download the pre-trained yolov4-tiny weights

```
[ ]: # Download the yolov4-tiny pre-trained weights file
[!] wget https://github.com/AlexeyAB/darknet/releases/download/darknet_yolo_v4_pre/
    ↪ yolov4-tiny.conv.29

# Download the yolov4 pre-trained weights file
[!] wget https://github.com/AlexeyAB/darknet/releases/download/darknet_yolo_v4_pre/
    ↪ yolov4.conv.137
```

14 10) Training

14.1 To restart your training (In case the training does not finish and you get disconnected)

If you get disconnected or lose your session, you don't have to start training your model from scratch again. You can restart training from where you left off. Use the weights that were saved last. The weights are saved every 100 iterations as *yolov4-tiny-custom_last.weights* in the *yolov4-tiny/training* folder on your drive. (The path we gave as backup in "obj.data" file).

Run the command below to restart training.

```
[ ]: #to restart training your custom detector where you left off(using the weights
    ↪ that were saved last)
[!] ./darknet detector train data/obj.data cfg/yolov4-custom.cfg /mydrive/yolo/
    ↪ training/yolov4-custom_last.weights -dont_show -map

[ ]: #to restart training your custom detector where you left off(using the weights
    ↪ that were saved last)
[!] ./darknet detector train data/obj.data cfg/yolov4-tiny-custom.cfg /mydrive/
    ↪ yolo/training/yolov4-tiny-custom_last.weights -dont_show -map
```

14.2 Train your custom detector

For best results, you should stop the training when the average loss is less than 0.05 if possible or at least constantly below 0.3, else train the model until the average loss does not show any significant change for a while.

```
[ ]: # train your custom detector! (uncomment %%capture below if you run into memory
    ↪ issues or your Colab is crashing)
# %%capture

[!] ./darknet detector train data/obj.data cfg/yolov4-custom.cfg yolov4.conv.137
    ↪ -dont_show -map

[ ]: # train your custom detector! (uncomment %%capture below if you run into memory
    ↪ issues or your Colab is crashing)
# %%capture
```

```
!./darknet detector train data/obj.data cfg/yolov4-tiny-custom.cfg yolov4-tiny.  
↪conv.29 -dont_show -map
```

```
[ ]: # This stops 'Run all' at this cell by causing an error  
assert False
```

```
[ ]: # quit colab  
!kill -9 -1
```

15 Now you can download and use your weights file from your google drive!

I have uploaded some of the files needed for training on my github link below.

- [JiaPai12138/AI-M-BOT](#)

16